

Design Models

How to Use LTspice® Models

ROHM provides the LTspice models for simulating electrical circuits. This application note explains how to add models to LTspice.

Contents


1. How to obtain the models	2
2. Model types	4
3. File configuration of LTspice	5
4. How to use models: Device Models.....	6
4-1. Confirming the device models	6
4-2. How to add the device models.....	6
4-2-1. Method 1: Add the model to the standard parts library of LTspice	7
4-2-2. Method 2: Describe the model information on the circuit diagram.....	10
4-2-3. Method 3: Store the model in a desired parts folder	12
5. How to use models: Subcircuit Models.....	16
5-1. Confirming the subcircuit models	16
5-2. How to add the subcircuit models.....	16
5-2-1. Method 1: Describe the model information on the circuit diagram.....	17
5-2-2. Method 2: Store the model in a desired parts folder	21
6. How to create circuit diagram symbols	29
Appendix A: Circuit symbol file	31
Appendix B: Circuit symbol file	32
Appendix C: Circuit symbol file.....	33
Appendix D: Circuit symbol file.....	34
Appendix E: Circuit symbol file.....	35
Appendix F: Circuit symbol file	36
Appendix G: Circuit symbol file.....	37
Appendix H: Circuit symbol file.....	38
Appendix I: Circuit symbol file	39
Appendix J: Circuit symbol file	40

LTspice® is a registered trademark of Analog Devices, Inc.

1. How to obtain the models


Step 1

- Access the ROHM website. Enter the product model name in the "Search ROHM" box on the upper right of the home page.




Step 2

- Click on the applicable model name in the search results.




Step 3

- When the product page is displayed, click “Tools”.
- The “Models” window opens. Locate and click the LTspice model.



Step 4

- When “LICENSE AGREEMENT” is displayed, check “I accept the License Agreement.” and click “Download” to download the file.



2. Model types

The models are classified into two types: device model and subcircuit model. You can check the syntax by opening the downloaded file with a text editor. The device models cover single elements, including bipolar transistors and diodes. The syntax starts with “.MODEL”. The subcircuit models cover configurations with multiple elements, including MOSFET, SiC power devices, and IGBT. The syntax starts with “.SUBCKT” and ends with “.ENDS”. Among the subcircuit models, the models for MOSFET are described as macro models representing MOSFET with equivalent circuits configured with the passive and active elements and the power supply. As a result, there are multiple “.MODEL”. SiC power devices and IGBT are described as behavior models representing the device characteristics with specific numerical expressions.

Model types	Device model	Subcircuit model	
First command	.MODEL	.SUBCKT	
Main devices	Bipolar transistor Diode LED	MOSFET (macro model) SiC power device (behavior model) IGBT (behavior model) Bi-directional TVS diode (macro model) Digital Transistor (macro model) Darlington Transistor (macro model) Complex Transistor (macro model) Laser Diode (behavior model)	
Syntax examples	<pre>* Q2SC4081UB NPN BJT model * Date: 2006/11/30 .MODEL Q2SC4081UB NPN + IS=70.000E-15 + BF=277.08 + VAF=114.03 + IKF=1 + ISE=70.000E-15 + NE=1.8934 + BR=11.565 + VAR=100 + IKR=.11266 + ISC=1.0228E-12 + NC=1.3260 + NK=.71869 + RE=.2 + RB=13.897 + RC=1.2190 + CJE=11.342E-12 + MJE=.38289 + CJC=4.0230E-12 + MJC=.34629 + TF=338.92E-12 + XTF=4.0449 + VTF=167.36 + ITF=.85959 + TR=110.25E-9 + XTB=1.5000</pre>	<pre>Macro model * R6006JNX NMOSFET model * PKG: TO-220FM,Vdss=600V,Id=6A * Rds(on)=0.72Ω,Qg=15.5nC * Model Generated by ROHM * All Rights Reserved * Date: 2017/07/27 *****D G S .SUBCKT R6006JNX 1 2 3 M1 11 22 3 3 MOS_N D1 3 1 DDS R1 1 11 RTH 697.2m D2 22 11 DDG R2 2 22 14.8 .MODEL MOS_N NMOS + LEVEL=3 + L=2.000E-6 + W=1 : (omitted) + KAPPA=0 + NFS=36G .MODEL DDS D + IS=2.2476E-6 + N=2.1699 : (omitted) + BV=600 + TT=70n .MODEL DDG D + CJO=172.09E-12 + M=3.3976 : (omitted) + FC=0.11 + T_ABS=25 .MODEL RTH RES + TC1=0.0073 + TC2=0.0200E-3 .ENDS R6006JNX</pre>	<pre>Behavior model * SCT4018KR SiC NMOSFET model * T0247-4L * 1200V 90A 18mOhm * Model Generated by ROHM * All Rights Reserved * DATE:2022/02/03 *****D G S DS .SUBCKT SCT4018KR 1 2 3 4 .PARAM T0=25 * .FUNC R1(I) {18.49m*I*EXP((TEMP-T0)/207.9*EXP((TEMP-T0)/880))+905.2n*I*ABS(I)**1.745*EXP((TEMP-T0)/160.2*EXP((TEMP-T0)/348.4))} .FUNC R2(I) {5*MAX(I,0)+5*MIN(I,0)} .FUNC V1(V,W) {V-67.95m*ASINH(W/17.87m)*EXP((TEMP-T0)/-323.4)-270.9m*ASINH(W/693.3m)*EXP((TEMP-T0)/-260.5)-43.83m*W*EXP((TEMP-T0)/3.368k)} : : (omitted) : V12 52 53 0 C11 53 1 1p G11 52 1 VALUE={I11(MIN(MAX(V(52,1),-4.5k),3.6))+I(V12)*C11(MAX(V(52,1),625.6m),MIN(V(52,1),625.6m))} R11 52 1 1T .ENDS SCT4018KR</pre>

3. File configuration of LTspice

When LTspice is installed, files are created in the configuration as shown in Figure 1. The folders related to the model and symbol files are `¥cmp`, `¥sub`, and `¥sym` under `¥LTspiceXVII¥lib`. Folder `¥cmp` stores the standard parts libraries, which are created with the device models. Folder `¥sub` stores the libraries other than those for the standard parts, which are mainly created with the subcircuit models. Naturally, it can also store the device models. Folder `¥sym` stores the circuit diagram symbol files. The model files in folder `¥sub` and the circuit diagram symbol files (`.asy`) in folder `¥sym` are linked so that they can be used on circuit diagrams.

In the following, we explain several ways for adding the models. Remember the configuration of these folders because the storage folder depends on the method used to add device models.

C:¥Users¥<user_name>¥Documents¥LTspiceXVII¥lib

- ¥cmp : Stores the standard parts libraries (device models)
 - ¥standard.bead : Ferrite bead
 - ¥standard.bjt : Bipolar transistor
 - ¥standard.cap : Capacitor
 - ¥standard.dio : Diode
 - ¥standard.ind : Inductor
 - ¥standard.jft : JFET
 - ¥standard.mos : MOSFET
 - ¥standard.res : Resistor
- ¥sub : Stores the libraries other than those described above (subcircuit and device models)
 - ¥xxxxxxx.sub : sub file
 - ¥xxxxxxx.lib : lib file
- ¥sym : Stores the circuit diagram symbol files
 - ¥xxxxxxx.asy : Circuit diagram symbol

Figure 1. Folder configuration and libraries of LTspice

4. How to use models: Device Models

4-1. Confirming the device models

For ROHM's product, the device models of bipolar transistors, diodes, and LED are provided. Open the downloaded model file with a text editor and confirm that the syntax starts with ".MODEL".

4-2. How to add the device models


We explain three methods to add device models here. Since each method has advantages and disadvantages, select the method most suited for your application.

	Method 1	Method 2	Method 3
	Add the model to the standard parts library of LTspice	Describe the model information on the circuit diagram	Store the model in a desired parts folder
Outline of the procedure	<ol style="list-style-type: none"> 1. Open the standard library 2. Copy the model file to be added to the standard library in text format 3. Place the symbol on the circuit diagram 4. Select the model from the parts list 	<ol style="list-style-type: none"> 1. Place the symbol on the circuit diagram 2. Copy the model file to be added to "SPICE directive" in text format 3. Place the model text on the circuit diagram 4. Change the attribute of the symbol 	<ol style="list-style-type: none"> 1. Store the model file to be added 2. Place the symbol on the circuit diagram 3. Change the model name of the symbol 4. Write the command to read the ".lib" file in the circuit diagram
Advantages	- Can be selected from the parts list	<ul style="list-style-type: none"> - Since the parameters of the parts are displayed on the circuit diagram, the evidence of simulation can be checked with the circuit diagram only - Since simulations can be performed with the circuit diagram data only, they are independent of the PC environment 	- Easy to manage the parts because they can be classified using folders
Disadvantages	- Reinstalling LTspice will overwrite the standard library, deleting the added models	<ul style="list-style-type: none"> - Many characters on the circuit diagram - Necessary to manage the parameters of the parts for each circuit diagram 	- Necessary to redo the environment setting of the model files if the PC environment changes


In the following, we explain the procedure in more detail for each method.

4-2-1. Method 1: Add the model to the standard parts library of LTspice


1. Click "File" and then "Open".
2. When the "Open an existing file" window is displayed, move to "Documents\LTspiceXVII\lib\cmp".
3. Select one of the following files corresponding to the part to be added. In this example, the NPN transistor model "2sc4081ub.lib" is added.
 - Bipolar transistor: standard.bjt
 - Diode: standard.dio
 - LED: standard.dio
4. Click "Open".



5. "standard.bjt" is opened.




6. Open the model to be added with a text editor (e.g. Notepad).
7. Copy the contents to the last line of "standard.bjt". At this time, you may delete unnecessary comment lines.
8. Click "File" and then "Save" to save changes. The model is now added.




Next, place the transistor on the circuit diagram.

9. On the toolbar, click the “Component” icon to open “Select Component Symbol”.
10. From the list, select “npn” and then click “OK”. Select “pnp” for a PNP transistor, “diode” for a diode, and “LED” for an LED.




11. After placing the component on the circuit diagram, right-click on it.
12. When the property window is opened, click “Pick New Transistor”.
13. When the “Select Bipolar Transistor” window is opened, select “Part No.” for the component added above.
14. The model name on the circuit diagram is changed. This completes the setting.




4-2-2. Method 2: Describe the model information on the circuit diagram

In this example, the NPN transistor model “2sc4081ub.lib” is added.



1. First, place the transistor on the circuit diagram. On the toolbar, click the “Component” icon to open “Select Component Symbol”.
2. From the list, select “npn” and then click “OK”. Select “pnp” for a PNP transistor, “diode” for a diode, and “LED” for an LED.
3. Place the component on the circuit diagram.



4. Open the model to be added with a text editor (e.g. Notepad).
5. On the toolbar, click “SPICE directive” to open the input window.
6. Copy the contents of the model and then click “OK”. At this time, you may delete unnecessary comment lines.



7. Place the model text at an appropriate location on the circuit diagram.
8. Right-click on "NPN" of the transistor.
9. When the input window is opened, rename "NPN" with the model name and then click "OK".
10. The model name on the circuit diagram is changed. This completes the setting.



4-2-3. Method 3: Store the model in a desired parts folder

We first explain how to store and use the model in folder “~\lib\sub” as described in “File configuration of LTspice”.


To distinguish the added models from the models installed as standard, you can create a folder in the “\sub” folder and store the added models there. You can also store the added models in the same folder as the circuit diagram or in a completely different location. In this way, you can store and use the models in a location where it is easy to manage them.

Examples of folders to store the models



- a. Standard folder : C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub
- b. Separation in the standard folder : C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub\MyLib
: C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub\ROHM
e.g., company name
- c. Same folder as the circuit diagram : D:\project-a\test_circuit ← example
- d. Folder other than above : E:\LTspicemodel\transistor\ROHM ← example

As an example, we use a case where the NPN transistor model “2sc4081ub.lib” is stored in the standard folder.


1. Store the model to be added in folder “C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub”.



- Place the transistor on the circuit diagram. On the toolbar, click the “Component” icon to open “Select Component Symbol”.
- From the list, select “npn” and then click “OK”. Select “pnp” for a PNP transistor, “diode” for a diode, and “LED” for an LED.
- Place the component on the circuit diagram.




- Right-click on “NPN” of the transistor.
- When the input window is opened, rename “NPN” with the model name and then click “OK”. For the model name to be entered, open the “.lib” file and use the model name written on the “.MODEL” line.
- The model name on the circuit diagram is changed.



```

2sc4081ub.lib - Notepad
File Edit Format View Help
* Q2SC4081UB NPN BJT model
* Date: 2006/11/30
.MODEL Q2SC4081UB NPN
+ IS=70.000E-15
+ BF=277.08
+ VAF=114.03
+ IKF=1
+ ISE=70.000E-15
+ NE=1.8934
+ BR=11.565
+ VAR=100
+ IKR=.11266
    
```




Next write the command to read the “.lib” file on the circuit diagram.

8. On the toolbar, click “SPICE directive” to open the input window.
9. Enter “.lib <filename>” in the entry field. Note that <filename> should be the file name stored in the parts folder, but not the model name provided to the circuit symbol above. The format for describing <filename> depends on where the model is stored. Refer to the following for more details. After completing the input, click “OK”.

You can also use the “.include” and “.inc” commands in addition to “.lib”.

Syntax	.lib <filename>
	.include <filename>
	.inc <filename>




Description of <filename> depends on where the model is stored.

- a. Standard folder : C:\%Users%\<user_name>\Documents\LTspiceXVII\lib\sub
 → Describe the file name only
 Syntax example: `.lib 2sc4081ub.lib`
- b. Separation in the standard folder : C:\%Users%\<user_name>\Documents\LTspiceXVII\lib\sub\MyLib
 → Describe “MyLib” and the file name
 Syntax example: `.lib MyLib\2sc4081ub.lib`
- c. Same folder as the circuit diagram: D:\%project-a%\test_circuit ← example
 → Describe the file name only
 Syntax example: `.lib 2sc4081ub.lib`
- d. Folder other than above : E:\LTspicemodel\transistor\ROHM ← example
 → Describe the absolute path
 Syntax example: `.lib E:\LTspicemodel\transistor\ROHM\2sc4081ub.lib`

For b and d above, you can also describe the file name only. In such cases, it is necessary to define the storage location of the device model files as described on the next page.

10. Place the command to read the “.lib” file at an appropriate location on the circuit diagram. This completes the setting.



The steps below must be performed if you describe only the file name in the “.lib” syntax in cases b and d on the previous page.

Define the storage location of the device model files. If the model storage location is changed, this method allows you to change the setting by batch on the Control Panel. Therefore, this method is more convenient compared with describing the absolute path of the model storage location in the “.lib” syntax.

11. On the toolbar, click the “Control Panel” icon. On the “Control Panel”, open the “Sym. & Lib. Search Paths” tab.
12. In the “Library Search Path[*]” field, describe the path of the folder where the circuit model files are stored. The format for describing the path depends on the storage location as follows.

b. Separation in the standard folder : C:\Users\%<user_name>\Documents\LTspiceXVII\lib\sub\MyLib

→ Describe the absolute path

Example of description:


C:\Users\%<user_name>\Documents\LTspiceXVII\lib\sub\MyLib

d. Folder other than above : E:\LTspice\mosfet\ROHM ← example

→ Describe the absolute path

Example of description: E:\LTspice\mosfet\ROHM

13. After completing the entry, click “OK”. This completes the setting.



5. How to use models: Subcircuit Models

5-1. Confirming the subcircuit models

For ROHM's products, the subcircuit models of MOSFET, SiC power devices, and IGBT are provided. Open the downloaded model file with a text editor and confirm that the syntax starts with ".SUBCKT".

5-2. How to add the subcircuit models

We explain two methods to add subcircuit models here. Since each method has advantages and disadvantages, select the method most suited for your application.


	Method 1 Describe the model information on the circuit diagram	Method 2 Store the model in a desired parts folder
Outline of the procedure	<ol style="list-style-type: none"> 1. Place the symbol on the circuit diagram 2. Copy the model file to be added to "SPICE directive" in text format 3. Place the model text on the circuit diagram 4. Change the attributes of the symbol 	<ol style="list-style-type: none"> 1. Store the model file to be added in a folder 2. Create a circuit diagram symbol 3. Link the symbol and the model file 4. Define the storage location of the symbol and the model file 5. Place the symbol on the circuit diagram
Advantages	<ul style="list-style-type: none"> - Since the parameters of the parts are displayed on the circuit diagram, the simulation evidence can be checked with the circuit diagram only - Since simulations can be performed with the circuit diagram data only, they are independent of the PC environment 	<ul style="list-style-type: none"> - Easy to manage the parts because they can be classified using folders
Disadvantages	<ul style="list-style-type: none"> - Many characters on the circuit diagram - Necessary to manage the parameters of the parts for each circuit diagram 	<ul style="list-style-type: none"> - Requires tasks including creating the circuit diagram symbol and linking the symbol and the model file - Necessary to redo the environment setting of the symbols and the model files if the PC environment changes

In the following, we explain the procedure in more detail for each method.


5-2-1. Method 1: Describe the model information on the circuit diagram

In this example, the Nch MOSFET “r6006jnx.lib” is added.

1. First, place the symbol on the circuit diagram. On the toolbar, click the “Component” icon to open “Select Component Symbol”.
2. From the list, select “nmos” and then click “OK”. For Pch MOSFET, select “pmos”. If the symbol you need is not listed, it must be created. We explain the method later.
3. Place the component on the circuit diagram.



4. Open the model to be added with a text editor (e.g. Notepad).
5. On the toolbar, click “SPICE directive” to open the input window.
6. Copy the contents of the model and then click “OK”. At this time, you may delete unnecessary comment lines.



7. Place the model text at an appropriate location on the circuit diagram.
8. Ctrl + right-click on the circuit symbol.
9. When "Component Attribute Editor" is opened, change the attributes.
 - For the subcircuit models, update "Prefix" with "X".
 - Update "Value" with the model name described in the ". SUBCKT" syntax of the subcircuit model file.
10. Click "Open Symbol" and check if the pin layout of the subcircuit model file (r6006jnx.lib) matches that of the circuit symbol (nmos.asy).

The image illustrates the process of configuring an LTspice model. It shows a circuit diagram with an NMOS transistor (M1) and its associated attributes (VGS, VDS). A 'Component Attribute Editor' dialog is open, showing the 'Value' field set to 'NMOS' and the 'Prefix' field set to 'MN'. A netlist snippet is shown on the right, detailing the subcircuit definition for R6006JNX, including parameters like Rds(on), Qg, and various model coefficients.

Component Attribute Editor

Open Symbol: #Documents%LTspice

This is the second attribute to appear on the netlist line.

Attribute	Value	Vis.
Prefix	MN	
InstName	M1	X
SpiceModel		
Value	NMOS	X
Value2		

Netlist Snippet:

```


* R6006JNX NMOSFET model
* PKG: TO-220FM,Vdss=600V,Id=6A
* Rds(on)=0.72Ω,Qg=15.5nC
* Model Generated by ROHM
* All Rights Reserved
* Commercial Use or
* Resale Restricted
* Date: 2017/07/27
*****D G S
.SUBCKT R6006JNX 1 2 3
M1 11 22 3 3 MOS_N
D1 3 1 DDS
R1 1 11 RTH 697.2m
D2 22 11 DDG
R2 2 22 4.8
.MODEL MOS_N NMOS
+ LEVEL=3
+ L=2.0000E-6
+ W=1
+ KP=10.817E-6
+ RS=10.000E-3
+ RD=0
+ VTO=-6.8118
+ RDS=6.0000E6
+ TOX=2.0000E-6
+ CGSO=374p
+ CGDO=1.1p
+ CBD=0
+ RG=0
+ N=2
+ RB=1.0000E-3
+ GAMMA=4.4
    
```

11. The Nch MOSFET symbol (nmos.asy) is displayed in a new tab.
12. Right-click on the symbol of the Drain pin to open its property window. Check "Label" and "Netlist Order".
13. Check the Gate and Source pins in the same way. The results are shown below. It is confirmed that the pins are assigned 1, 2, and 3 in the order of D, G, and S.

Label: D Netlist Order: 1

Label: G Netlist Order: 2

Label: S Netlist Order: 3





14. Check the order described in the subcircuit model file (r6006jnx.lib). The order is D, G, and S from the left. Therefore, the order is confirmed to be the same as the symbol setting.
15. Note that “1 2 3” in the “.SUBCKT R6006JNX 1 2 3” syntax described in r6006jnx.lib is the node numbers of the subcircuit and not related to the numbers in “Netlist Order”.
16. It should also be noted that the numbers in “Netlist Order” are not the pin numbers described in the data sheet.
17. On the menu bar, click “File” and then “Close” to close the symbol. This completes the setting.

```

r6006jnx.lib - Notep...
File Edit Format View Help
* R6006JNX NMOSFET model
* PKG: TO-220FM, Vdss=600V, Id=6A
* Rds(on)=0.72Ω, Qg=15.5nC
* Model Generated by ROHM
* All Rights Reserved
* Commercial Use or
* Resale Restricted
* Date: 2017/07/27
*****D G S
.SUBCKT R6006JNX 1 2 3
M1 11 22 3 3 MOS_N
D1 2 1 DNS
    
```

16 Pin numbers described in the data sheet



5-2-2. Method 2: Store the model in a desired parts folder

We first explain how to store and use the model in folder “~\lib\sub” as described in “File configuration of LTspice”.


To distinguish the added models from the models installed as standard, you can create a folder in the “\sub” folder and store the added models. You can also store the added models in the same folder as the circuit diagram or in a completely different location. In this way, you can store and use the models in a location where it is easy to manage them.

Examples of folders to store the models

- a. Standard folder : C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub
- b. Separation in the standard folder : C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub\MyLib
: C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub\ROHM ↑ e.g. company name
- c. Same folder as the circuit diagram : D:\project-a\test_circuit ← example
- d. Folder other than above : E:\LTspicemodel\transistor\ROHM ← example


As an example, we use a case where the Nch MOSFET model “r6006jnx.lib” is stored in the standard folder.

1. Store the model to be added in the folder “C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub”.







Create the circuit diagram symbol by using a circuit diagram symbol provided as standard


- Copy "nmos.asy" in folder "C:\Users\%<user_name>\Documents\LTspiceXVII\lib\sym". If no standard symbol can be adapted, the symbol must be created using the method described below.
- Change the name to "R6006JNX.asy". In this example, the name is the same as the subcircuit model file name. However, this is not required and you can use any name recognizable to users.



- Open "R6006JNX.asy" with LTspice. On the menu bar, select "Edit" → "Attributes" → "Edit Attributes".
- When "Symbol Attribute Editor" is opened, change the attributes.
 - For the subcircuit models, update "Prefix" with "X".
 - Update "Value" with the model name described in the ". SUBCKT" syntax of the subcircuit model file.
 - Enter the subcircuit model file name in "ModelFile".
- Click "OK".



7. The circuit symbol is now changed to "R6006JNX".



Next, check if the pin layout of the subcircuit model file (r6006jnx.lib) matches that of the circuit symbol (R6006JNX.asy).


8. Right-click on the Drain pin symbol to open its property window. Check "Label" and "Netlist Order".

9. Check the Gate and Source pins in the same way. The results are shown below. It is confirmed that the pins are assigned 1, 2, and 3 in the order of D, G, and S.

Label: D Netlist Order: 1

Label: G Netlist Order: 2

Label: S Netlist Order: 3




10. Check the order described in the subcircuit model file (r6006jnx.lib). The order is D, G, and S from the left. Therefore, the order is confirmed to be the same as the symbol setting. If they don't match, change the order of "Netlist Order".
11. Note that "1 2 3" in the ".SUBCKT R6006JNX 1 2 3" syntax described in r6006jnx.lib is the node numbers of the subcircuit and not related to the numbers in "Netlist Order".
12. It should also be noted that the numbers in "Netlist Order" are not the pin numbers described in the data sheet.
13. On the menu bar, click "File" and then "Save" to save changes. Click "File" and then "Close" to close the symbol. This completes the setting.

```

r6006jnx.lib - Notep...
File Edit Format View Help
* R6006JNX NMOSFET model
* PKG: TO-220FM, Vdss=600V, Id=6A
* Rds(on)=0.72Ω, Qg=15.5nC
* Model Generated by ROHM
* All Rights Reserved
* Commercial Use or
* Resale Restricted
* Date: 2017/07/27
*****D G S
.SUBCKT R6006JNX 1 2 3
M1 11 22 3 3 MOS_N
D1 3 1 DDS
    
```

12 Pin numbers described in the data sheet




Define the storage location of the symbol file.

It is not necessary to define the storage location if the symbol file is stored in the standard folder like this example. However, the storage location must be defined if the symbol file is stored in a desired location.

14. On the toolbar, click the “Control Panel” icon. On the “Control Panel”, open the “Sym. & Lib. Search Paths” tab.
15. In the “Symbol Search Path[*]” field, describe the path of the folder where the circuit symbols are stored. The format for describing the path depends on the storage location as follows.

- a. Standard folder : C:\Users\<user_name>\Documents\LTspiceXVII\lib\sym
→ No definition required
- b. Separation in the standard folder : C:\Users\<user_name>\Documents\LTspiceXVII\lib\sym\MyLib
C:\Users\<user_name>\Documents\LTspiceXVII\lib\sym\ROHM
→ No definition required
- c. Folder other than above : E:\LTspice\mosfet\ROHM ← example
→ Describe the absolute path
Example of description: E:\LTspice\mosfet\ROHM

16. After completing the entry, click “OK”.



Define the storage location of the subcircuit model files.

It is not necessary to define the storage location if the subcircuit model file is stored in the standard folder like this example. However, the storage location must be defined if the symbol file is stored in a desired location.

17. On the toolbar, click the “Control Panel” icon. On the “Control Panel”, open the “Sym. & Lib. Search Paths” tab.
18. In the “Library Search Path[*]” field, describe the path of the folder where the circuit model files are stored. The format for describing the path depends on the storage location as follows.

a. Standard folder : C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub
 → No definition required

b. Separation in the standard folder : C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub\MyLib
 C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub\ROHM
 → Describe the absolute path

Example of description: C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub\MyLib


Example of description: C:\Users\<user_name>\Documents\LTspiceXVII\lib\sub\ROHM

c. Same folder as the circuit diagram: D:\project-a\test_circuit ← example
 → No definition required

d. Folder other than above : E:\LTspice\mosfet\ROHM ← example
 → Describe the absolute path

Example of description: E:\LTspice\mosfet\ROHM


19. After completing the entry, click “OK”.



It is also possible to describe the path of the folder and place the symbol on the circuit diagram using the “.lib”, “.include”, and “.inc” syntaxes. However, if the model storage location is changed, the method described above is more convenient because it allows you to define the storage location on the Control Panel to change the settings by batch.

Place the circuit symbol on the circuit diagram.




20. On the toolbar, click the “Component” icon to open “Select Component Symbol”.
21. From the list, select “R6006JNX” created above. If the symbol is stored in a location other than the standard folder (~¥LTspiceXVII¥/lib/sym), switch “Top Directory”. The newly added symbol may not be displayed immediately. In such cases, the symbol will be displayed after restarting LTspice.
22. Click “OK”.
23. Place the component on the circuit diagram. This completes the setting.




Supplementary: Precautions for matching the pin layouts of the subcircuit model file (.lib) and the circuit symbol (.asy)

For devices with a small number of pins, such as transistors, the net list and the property window of a circuit symbol show numbers “1”, “2”, and “3”. The internal circuit diagram in the data sheet also shows “1”, “2”, and “3”. Since these numbers have different meanings in these contexts, be careful not to consider them identical. Doing so will result in incorrect settings.

The table below summarizes the meaning of the numbers in each context. The numbers in the model file represent the node numbers of the subcircuit. They are different from the numbers in “Netlist Order” of the symbol or the pin numbers of the product. In this example, the node numbers are 1, 2, and 3 for D, G, and S, respectively, by chance. This causes a more confusing situation where the node numbers may be mistaken for the pin numbers. The numbers in “Netlist Order” of the circuit symbol represent the order of the pins described on the net list. In this example, “1” indicates that “D” is the leftmost pin on the net list. Similarly, “2” indicates that “G” is the second pin from left on the net list, and “3” indicates that “S” is the third pin from left on the net list. The numbers shown on the internal circuit diagram in the data sheet are the pin numbers of the product. These numbers are used for the physical pin layout.

Model file (net list)	Circuit symbol	Internal circuit diagram in the data sheet
Node numbers of the subcircuit	Order of the pins described in the net list	Pin numbers of the product
		

The figure below summarizes the details for matching the pin layouts. 1. Match the order of the pins described in the subcircuit model file with the order in “Netlist Order” of the circuit diagram symbol. 2. To display the physical pin layout shown in the data sheet as the symbol information, define it in the “Label” field.



6. How to create circuit diagram symbols

You can create symbols that are not provided as standard, such as SiC MOSFET and IGBT. Although it is possible to create a symbol from scratch using the “Draw” tool, it takes a long time with this method. Therefore, we explain how to create a symbol from a provided symbol file (.asy). The circuit symbol files are shown as appendices to this application note. Select the required symbol from the appendices to create your symbol.


1. Open a new file with a text editor (Notepad). Copy and paste the text data section of the symbol to be created from the appendices to the new file.

How to Use LTspice Models: Subcircuit Models
Application Note

Appendix A: Circuit symbol file

Device: 3pin SiC MOSFET

Symbol:



Symbol file name: SiCmosfet-3.asy


Text data:

```

----- Start -----
Version 4
SymbolType CELL
LINE Normal 48 48 48 96
LINE Normal 32 48 32 48
LINE Normal 48 32 48 0
LINE Normal 48 32 48 32
LINE Normal 32 32 48 32
LINE Normal 32 64 48 64
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 48 71 64 71
LINE Normal 68 53 60 53
LINE Normal 64 45 68 53
LINE Normal 60 53 64 45
LINE Normal 48 25 64 25
LINE Normal 48 80 0 80
LINE Normal 64 71 64 25
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 46 42 37 48
LINE Normal 46 54 37 48
LINE Normal 32 48 48 48
CIRCLE Normal 85 86 9 8
WINDOW 0 96 32 Left 2
WINDOW 3 96 72 Left 2
SYMATTR Value SCTxxxx
SYMATTR Prefix X
SYMATTR Description ROHM SiC MOSFET
SYMATTR ModelFile xxxx.lib
PIN 48 0 NONE 0
PINATTR PinName D
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 48 96 NONE 0
PINATTR PinName S
PINATTR SpiceOrder 3
----- End -----
    
```

```

Version 4
SymbolType CELL
LINE Normal 48 48 48 96
LINE Normal 32 48 32 48
LINE Normal 48 32 48 0
LINE Normal 48 32 48 32
LINE Normal 32 32 48 32
LINE Normal 32 64 48 64
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 48 71 64 71
LINE Normal 68 53 60 53
LINE Normal 64 45 68 53
LINE Normal 60 53 64 45
LINE Normal 48 25 64 25
LINE Normal 48 80 0 80
LINE Normal 64 71 64 25
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 46 42 37 48
LINE Normal 46 54 37 48
LINE Normal 32 48 48 48
CIRCLE Normal 85 86 9 8
WINDOW 0 96 32 Left 2
WINDOW 3 96 72 Left 2
SYMATTR Value SCTxxxx
SYMATTR Prefix X
SYMATTR Description ROHM SiC MOSFET
SYMATTR ModelFile xxxx.lib
PIN 48 0 NONE 0
PINATTR PinName D
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 48 96 NONE 0
PINATTR PinName S
PINATTR SpiceOrder 3
    
```



- Open the subcircuit model corresponding to the symbol with a text editor. Enter the model name described in the “.SUBCKT” syntax for the value of the “SYMATTR Value” syntax in the symbol file being created.
- Enter the file name of the subcircuit model for the value of the “SYMATTR ModelFile” syntax in the symbol file being created.

Subcircuit model file (.lib)

Symbol file being created (.asy)

```
sct4018kr.lib - Notepad
File Edit Format View Help
* SCT4018KR
* SiC NMOSFET model
* T0247-4L
* 1200V 90A 18mOhm
* Model Generated by ROHM
* All Rights Reserved
* Commercial Use or Resale Restricted
* DATE:2022/02/03
*****D G S DS
.SUBCKT SCT4018KR 1 2 3 4
.PARAM TU=25
*
.FUNC R1(I) [18.49m*I*EXP((TEMP-T0)/207.9:
+ 905.2n*I*ABS(I)**1.745*EXP((
.FUNC R2(I) [5*MAX(I,0)+5*MIN(I,0)]
.FUNC V1(V,W) [V-67.95m*ASINH(W/17.87m)*EXP
+ 270.9m*ASINH(W/693.2m)*EXP((
.FUNC V2(V) [6.417f*V*(21.3)*EXP((TEMP-T0)
.FUNC I1(V,W) [V*(1+480.7m*(TANH((V-2.722)/:
+ W/(ABS(W)+480.7m*(TANH((V-2.722)/:
.FUNC C1(U,V,W) [(503.7*(V-778.8m)+1.545k*(1-:
+ (1+(TANH((U+2.342)/714m)-1)/:
V1 1 11 0
E1 11 12 VALUE={R1(MIN(MAX(I(V1),-8k),8k))*93.
V2 2 21 0
E2 21 22 VALUE={R2(I(V2))}
L1 3 32 10n
R2 3 32 10
R6 4 32 1m
E3 41 0 VALUE={V1(MIN(MAX(V(22),32)+139.8m,0)
E4 42 0 VALUE={V2(MIN(MAX(V(41),0),15))}
G1 12 32 VALUE={I1(MIN(MAX(V(42),0),700),V(12)
R3 12 32 1T
V3 22 23 0
C1 23 12 1p
E1 11 12 VALUE={R1(MIN(MAX(I(V1),-8k),8k))*93.
E2 21 22 VALUE={R2(I(V2))}
E3 41 0 VALUE={V1(MIN(MAX(V(22),32)+139.8m,0)
E4 42 0 VALUE={V2(MIN(MAX(V(41),0),15))}
G1 12 32 VALUE={I1(MIN(MAX(V(42),0),700),V(12)
R3 12 32 1T
V3 22 23 0
C1 23 12 1p
```


```
*Untitled - Notepad
File Edit Format View Help
Version 4
SymbolType CELL
LINE Normal 48 48 48 96
LINE Normal 32 48 32 48
LINE Normal 48 32 48 0
LINE Normal 48 32 48 32
LINE Normal 32 32 48 32
LINE Normal 32 64 48 64
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 48 71 64 71
LINE Normal 68 53 60 53
LINE Normal 64 45 68 53
LINE Normal 60 53 64 45
LINE Normal 68 45 60 45
LINE Normal 48 25 64 25
LINE Normal 48 80 0 80
LINE Normal 64 71 64 25
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 46 42 37 48
LINE Normal 46 54 37 48
LINE Normal 32 48 48 48
CIRCLE Normal 85 86 9 8
WINDOW 0 96 32 Left 2
WINDOW 3 96 12 Left 2
SYMATTR Value SCTxxxx
SYMATTR Prefix X
SYMATTR Description ROHM SiC MOSFET
SYMATTR ModelFile xxxx.lib
PIN 48 0 NONE 0
PINATTR PinName D
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
```

- Save the symbol file with an appropriate file name and extension “.asy” (e.g. SCT4018KR.asy). This completes the creation of the symbol.

Appendix A: Circuit symbol file

Device: 3pin SiC MOSFET

Symbol:



Symbol file name: SiCmosfet-3.asy

Text data:

```


----- Start -----
Version 4
SymbolType CELL
LINE Normal 48 48 48 96
LINE Normal 32 48 32 48
LINE Normal 48 32 48 0
LINE Normal 48 32 48 32
LINE Normal 32 32 48 32
LINE Normal 32 64 48 64
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 48 71 64 71
LINE Normal 68 53 60 53
LINE Normal 64 45 68 53
LINE Normal 60 53 64 45
LINE Normal 68 45 60 45
LINE Normal 48 25 64 25
LINE Normal 64 71 64 25
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 46 42 37 48
LINE Normal 46 54 37 48
LINE Normal 32 48 48 48
CIRCLE Normal 85 86 9 8
WINDOW 0 96 32 Left 2
WINDOW 3 96 72 Left 2
SYMATTR Value SCTxxxx
SYMATTR Prefix X
SYMATTR Description ROHM SiC MOSFET
SYMATTR ModelFile xxxx.lib
PIN 48 0 NONE 0
PINATTR PinName D
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 48 96 NONE 0
PINATTR PinName S
PINATTR SpiceOrder 3
----- End -----

```

Appendix B: Circuit symbol file

Device: 3-pin SiC MOSFET (coupled electro-thermal analysis model)

Symbol:



Symbol file name: SiCmosfet-3-therm.asy

Text data:

```


---- Start -----
Version 4
SymbolType CELL
LINE Normal 48 48 48 96
LINE Normal 32 48 32 48
LINE Normal 48 32 48 0
LINE Normal 48 32 48 32
LINE Normal 32 32 48 32
LINE Normal 32 64 48 64
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 48 71 64 71
LINE Normal 68 53 60 53
LINE Normal 64 45 68 53
LINE Normal 60 53 64 45
LINE Normal 68 45 60 45
LINE Normal 48 25 64 25
LINE Normal 64 71 64 25
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 46 42 37 48
LINE Normal 46 54 37 48
LINE Normal 32 48 48 48
RECTANGLE Normal 288 96 160 16
CIRCLE Normal 85 86 9 8
WINDOW 0 96 32 Left 2
WINDOW 3 96 0 Left 2
SYMATTR Value SCTxxxx
SYMATTR Prefix X
SYMATTR Description ROHM SiC MOSFET
SYMATTR ModelFile xxxx.lib
PIN 48 0 NONE 0
PINATTR PinName D
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 48 96 NONE 0
PINATTR PinName S
PINATTR SpiceOrder 3
PIN 192 96 BOTTOM 8
PINATTR PinName Tj
PINATTR SpiceOrder 4
PIN 256 96 BOTTOM 8
PINATTR PinName Ta
PINATTR SpiceOrder 6
PIN 288 32 RIGHT 8
PINATTR PinName Tc
PINATTR SpiceOrder 5
---- End -----

```


Appendix C: Circuit symbol file

Device: 4pin SiC MOSFET

Symbol:



Symbol file name: SiCmosfet-4.asy

Text data:

```


----- Start -----
Version 4
SymbolType CELL
LINE Normal 48 48 48 96
LINE Normal 32 48 32 48
LINE Normal 48 32 48 0
LINE Normal 48 32 48 32
LINE Normal 32 32 48 32
LINE Normal 32 64 48 64
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 48 71 64 71
LINE Normal 68 53 60 53
LINE Normal 64 45 68 53
LINE Normal 60 53 64 45
LINE Normal 68 45 60 45
LINE Normal 48 25 64 25
LINE Normal 48 80 0 80
LINE Normal 64 71 64 25
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 46 42 37 48
LINE Normal 46 54 37 48
LINE Normal 32 48 48 48
CIRCLE Normal 85 86 9 8
WINDOW 0 96 32 Left 2
WINDOW 3 96 72 Left 2
SYMATTR Value SCTxxxx
SYMATTR Prefix X
SYMATTR Description ROHM SiC MOSFET
SYMATTR ModelFile xxxx.lib
PIN 48 0 NONE 0
PINATTR PinName D
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 48 96 NONE 0
PINATTR PinName S
PINATTR SpiceOrder 3
PIN 0 80 NONE 8
PINATTR PinName DS
PINATTR SpiceOrder 4
----- End -----

```

Appendix D: Circuit symbol file

Device: 4-pin SiC MOSFET (coupled electro-thermal analysis model)

Symbol:



Symbol file name: SiCmosfet-4-therm.asy

Text data:


```

----- Start -----
Version 4
SymbolType CELL
LINE Normal 48 48 48 96
LINE Normal 32 48 32 48
LINE Normal 48 32 48 0
LINE Normal 48 32 48 32
LINE Normal 32 32 48 32
LINE Normal 32 64 48 64
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 48 71 64 71
LINE Normal 68 53 60 53
LINE Normal 64 45 68 53
LINE Normal 60 53 64 45
LINE Normal 68 45 60 45
LINE Normal 48 25 64 25
LINE Normal 48 80 0 80
LINE Normal 64 71 64 25
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 46 42 37 48
LINE Normal 46 54 37 48
LINE Normal 32 48 48 48
RECTANGLE Normal 288 96 160 16
CIRCLE Normal 85 86 9 8
WINDOW 0 96 32 Left 2
WINDOW 3 96 0 Left 2
SYMATTR Value SCTxxxx
SYMATTR Prefix X
SYMATTR Description ROHM SiC MOSFET
SYMATTR ModelFile xxxx.lib
PIN 48 0 NONE 0
PINATTR PinName D
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 48 96 NONE 0
PINATTR PinName S
PINATTR SpiceOrder 3
PIN 0 80 NONE 8
PINATTR PinName DS
PINATTR SpiceOrder 4
PIN 192 96 BOTTOM 8
PINATTR PinName Tj
PINATTR SpiceOrder 5
PIN 288 32 RIGHT 8
PINATTR PinName Tc
PINATTR SpiceOrder 6
PIN 256 96 BOTTOM 8
PINATTR PinName Ta
PINATTR SpiceOrder 7
----- End -----
    
```

Appendix E: Circuit symbol file

Device: IGBT

Symbol:



Symbol file name: IGBT.asy

Text data:

```


---- Start -----
Version 4
SymbolType CELL
LINE Normal 64 8 64 0
LINE Normal 64 8 64 8
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 64 96 64 88
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 64 8 32 32
LINE Normal 64 88 32 64
LINE Normal 53 64 32 48
LINE Normal 47 70 49 77
LINE Normal 43 78 49 77
LINE Normal 56 20 50 19
LINE Normal 52 12 50 19
WINDOW 0 80 32 Left 2
WINDOW 3 80 72 Left 2
SYMATTR Value RGxxxx
SYMATTR Prefix X
SYMATTR Description ROHM IGBT
SYMATTR ModelFile xxxx.lib
PIN 64 0 NONE 0
PINATTR PinName C
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 64 96 NONE 0
PINATTR PinName E
PINATTR SpiceOrder 3
---- End -----

```

Appendix F: Circuit symbol file

Device: IGBT (coupled electro-thermal analysis model)

Symbol:



Symbol file name: IGBT-therm.asy

Text data:

```


---- Start -----
Version 4
SymbolType CELL
LINE Normal 64 8 64 0
LINE Normal 64 8 64 8
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 64 96 64 88
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 64 8 32 32
LINE Normal 64 88 32 64
LINE Normal 53 64 32 48
LINE Normal 47 70 49 77
LINE Normal 43 78 49 77
LINE Normal 56 20 50 19
LINE Normal 52 12 50 19
RECTANGLE Normal 272 96 144 16
WINDOW 0 80 32 Left 2
WINDOW 3 80 0 Left 2
SYMATTR Value RGxxxx
SYMATTR Prefix X
SYMATTR Description ROHM IGBT
SYMATTR ModelFile xxxx.lib
PIN 64 0 NONE 0
PINATTR PinName C
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 64 96 NONE 0
PINATTR PinName E
PINATTR SpiceOrder 3
PIN 176 96 BOTTOM 8
PINATTR PinName Tj
PINATTR SpiceOrder 4
PIN 272 32 RIGHT 8
PINATTR PinName Tc
PINATTR SpiceOrder 5
PIN 240 96 BOTTOM 8
PINATTR PinName Ta
PINATTR SpiceOrder 6
---- End -----

```

Appendix G: Circuit symbol file

Device: IGBT with built-in fast recovery diode

Symbol:



Symbol file name: IGBT-frd.asy

Text data:

```


---- Start -----
Version 4
SymbolType CELL
LINE Normal 64 8 64 0
LINE Normal 64 8 64 8
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 80 88 80 8
LINE Normal 64 8 80 8
LINE Normal 64 96 64 88
LINE Normal 64 88 80 88
LINE Normal 88 55 72 55
LINE Normal 80 39 88 55
LINE Normal 72 55 80 39
LINE Normal 88 39 72 39
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 64 8 32 32
LINE Normal 64 88 32 64
LINE Normal 53 64 32 48
LINE Normal 47 70 49 77
LINE Normal 43 78 49 77
LINE Normal 56 20 50 19
LINE Normal 52 12 50 19
WINDOW 0 96 32 Left 2
WINDOW 3 96 72 Left 2
SYMATTR Value RGxxxx
SYMATTR Prefix X
SYMATTR Description ROHM IGBT
SYMATTR ModelFile xxxx.lib
PIN 64 0 NONE 0
PINATTR PinName C
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 64 96 NONE 0
PINATTR PinName E
PINATTR SpiceOrder 3
---- End -----

```

Appendix H: Circuit symbol file

Device: IGBT with built-in fast recovery diode (coupled electro-thermal analysis model)

Symbol:



Symbol file name: IGBT-frd-therm.asy

Text data:

```


----- Start -----
Version 4
SymbolType CELL
LINE Normal 64 8 64 0
LINE Normal 64 8 64 8
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 80 88 80 8
LINE Normal 64 8 80 8
LINE Normal 64 96 64 88
LINE Normal 64 88 80 88
LINE Normal 88 55 72 55
LINE Normal 80 39 88 55
LINE Normal 72 55 80 39
LINE Normal 88 39 72 39
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 64 8 32 32
LINE Normal 64 88 32 64
LINE Normal 53 64 32 48
LINE Normal 47 70 49 77
LINE Normal 43 78 49 77
LINE Normal 56 20 50 19
LINE Normal 52 12 50 19
RECTANGLE Normal 352 96 160 16
WINDOW 0 96 32 Left 2
WINDOW 3 96 0 Left 2
SYMATTR Value RGxxxx
SYMATTR Prefix X
SYMATTR Description ROHM IGBT
SYMATTR ModelFile xxxx.lib
PIN 64 0 NONE 0
PINATTR PinName C
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 64 96 NONE 0
PINATTR PinName E
PINATTR SpiceOrder 3
PIN 192 96 BOTTOM 8
PINATTR PinName Tjm
PINATTR SpiceOrder 4
PIN 256 96 BOTTOM 8
PINATTR PinName Tjd
PINATTR SpiceOrder 5
PIN 352 32 RIGHT 8
PINATTR PinName Tc
PINATTR SpiceOrder 6
PIN 320 96 BOTTOM 8
PINATTR PinName Ta
PINATTR SpiceOrder 7
----- End -----

```

Appendix I: Circuit symbol file

Device: IGBT with built-in Schottky barrier diode

Symbol:



Symbol file name: IGBT-sbd.asy

Text data:

```


---- Start -----
Version 4
SymbolType CELL
LINE Normal 64 8 64 0
LINE Normal 64 8 64 8
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 80 88 80 8
LINE Normal 64 8 80 8
LINE Normal 64 96 64 88
LINE Normal 64 88 80 88
LINE Normal 88 55 72 55
LINE Normal 80 39 88 55
LINE Normal 72 55 80 39
LINE Normal 88 39 72 39
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 64 8 32 32
LINE Normal 64 88 32 64
LINE Normal 53 64 32 48
LINE Normal 47 70 49 77
LINE Normal 43 78 49 77
LINE Normal 56 20 50 19
LINE Normal 52 12 50 19
LINE Normal 72 36 72 39
LINE Normal 76 36 72 36
LINE Normal 88 42 88 39
LINE Normal 84 42 88 42
WINDOW 0 96 32 Left 2
WINDOW 3 96 72 Left 2
SYMATTR Value RGxxxx
SYMATTR Prefix X
SYMATTR Description ROHM IGBT
SYMATTR ModelFile xxxx.lib
PIN 64 0 NONE 0
PINATTR PinName C
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 64 96 NONE 0
PINATTR PinName E
PINATTR SpiceOrder 3
---- End -----

```

Appendix J: Circuit symbol file

Device: IGBT with built-in Schottky barrier diode (coupled electro-thermal analysis model)

Symbol:



Symbol file name: IGBT-sbd-therm.asy

Text data:

```

---- Start -----
Version 4
SymbolType CELL
LINE Normal 64 8 64 0
LINE Normal 64 8 64 8
LINE Normal 24 64 24 32
LINE Normal 0 64 24 64
LINE Normal 80 88 80 8
LINE Normal 64 8 80 8
LINE Normal 64 96 64 88
LINE Normal 64 88 80 88
LINE Normal 88 55 72 55
LINE Normal 80 39 88 55
LINE Normal 72 55 80 39
LINE Normal 88 39 72 39
LINE Normal 32 54 32 42
LINE Normal 32 38 32 26
LINE Normal 32 70 32 58
LINE Normal 64 8 32 32
LINE Normal 64 88 32 64
LINE Normal 53 64 32 48
LINE Normal 47 70 49 77
LINE Normal 43 78 49 77
LINE Normal 56 20 50 19
LINE Normal 52 12 50 19
LINE Normal 72 36 72 39
LINE Normal 76 36 72 36
LINE Normal 88 42 88 39
LINE Normal 84 42 88 42
RECTANGLE Normal 352 96 160 16
WINDOW 0 96 32 Left 2
WINDOW 3 96 0 Left 2
SYMATTR Value RGxxxx
SYMATTR Prefix X
SYMATTR Description ROHM IGBT
SYMATTR ModelFile xxxx.lib
PIN 64 0 NONE 0
PINATTR PinName C
PINATTR SpiceOrder 1
PIN 0 64 NONE 0
PINATTR PinName G
PINATTR SpiceOrder 2
PIN 64 96 NONE 0
PINATTR PinName E
PINATTR SpiceOrder 3
PIN 192 96 BOTTOM 8
PINATTR PinName Tjm
PINATTR SpiceOrder 4
PIN 256 96 BOTTOM 8
PINATTR PinName Tjd
PINATTR SpiceOrder 5
PIN 352 32 RIGHT 8
PINATTR PinName Tc
PINATTR SpiceOrder 6
PIN 320 96 BOTTOM 8
PINATTR PinName Ta
PINATTR SpiceOrder 7
---- End -----

```


Notice

- 1) The information contained in this document is intended to introduce ROHM Group (hereafter referred to as ROHM) products. When using ROHM products, please verify the latest specifications or datasheets before use.
- 2) ROHM products are designed and manufactured for use in general electronic equipment and applications (such as Audio Visual equipment, Office Automation equipment, telecommunication equipment, home appliances, amusement devices, etc.) or specified in the datasheets. Therefore, please contact the ROHM sales representative before using ROHM products in equipment or devices requiring extremely high reliability and whose failure or malfunction may cause danger or injury to human life or body or other serious damage (such as medical equipment, transportation, traffic, aircraft, spacecraft, nuclear power controllers, fuel control, automotive equipment including car accessories, etc. hereafter referred to as Specific Applications). Unless otherwise agreed in writing by ROHM in advance, ROHM shall not be in any way responsible or liable for any damages, expenses, or losses incurred by you or third parties arising from the use of ROHM Products for Specific Applications.
- 3) Electronic components, including semiconductors, can fail or malfunction at a certain rate. Please be sure to implement, at your own responsibilities, adequate safety measures including but not limited to fail-safe design against physical injury, and damage to any property, which a failure or malfunction of products may cause.
- 4) The information contained in this document, including application circuit examples and their constants, is intended to explain the standard operation and usage of ROHM products, and is not intended to guarantee, either explicitly or implicitly, the operation of the product in the actual equipment it will be used. As a result, you are solely responsible for it, and you must exercise your own independent verification and judgment in the use of such information contained in this document. ROHM shall not be in any way responsible or liable for any damages, expenses, or losses incurred by you or third parties arising from the use of such information.
- 5) When exporting ROHM products or technologies described in this document to other countries, you must abide by the procedures and provisions stipulated in all applicable export laws and regulations, such as the Foreign Exchange and Foreign Trade Act and the US Export Administration Regulations, and follow the necessary procedures in accordance with these provisions.
- 6) The technical information and data described in this document, including typical application circuits, are examples only and are not intended to guarantee to be free from infringement of third parties intellectual property or other rights. ROHM does not grant any license, express or implied, to implement, use, or exploit any intellectual property or other rights owned or controlled by ROHM or any third parties with respect to the information contained herein.
- 7) No part of this document may be reprinted or reproduced in any form by any means without the prior written consent of ROHM.
- 8) All information contained in this document is current as of the date of publication and subject to change without notice. Before purchasing or using ROHM products, please confirm the latest information with the ROHM sales representative.
- 9) ROHM does not warrant that the information contained herein is error-free. ROHM shall not be in any way responsible or liable for any damages, expenses, or losses incurred by you or third parties resulting from errors contained in this document.



Thank you for your accessing to ROHM product informations.
More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

<https://www.rohm.com/contactus>